


Crimp O-Ring on Hose
to Stop Movement When
Operating UNI-VALVE

TOP Section of Pole



Brush Head

← WATER FLOW

Base of Pole



NOTE! Correct
UNI-VALVE
Valve Direction